

- 1) Find the centre of the canopy ceiling. Measure brickwork opening size and divide by two. Mark and trim off excess ceiling area as diagram below
- 2) Care should be taken not to bend or crush the canopy when cutting as this will cause hairline cracking of the gelcoat surface
- 3) Slide canopy onto frames allowing ceiling area to pass into the room, ensure canopy is tight against outer wall then mark the two corners of the internal plaster onto ceiling, remove canopy again and using your two marks draw a straight line and trim off the excess ceiling area.
- 4) The canopy can now be slid back into position
- 5) Drill top flange against wall and fix back with screws and rawlplugs. (Take care not to over tighten fixings as this will cause cracking of the gelcoat surface)
- 6) Drill through top of window frames and fix self-tapping screws into the ceiling of the canopy
- 7) Glaze windows as usual
- 8) Grind out groove in brickwork to accept lead flashing and install as usual
- 9) Clean off using non-abrasive cleaner or soap and water
- 10) Seal around walls and windows with silicone sealant

